

*business*phone  
...it's your business



*User's Guide*

BUSINESSPHONE 250  
BUSINESSPHONE 50

Basic Telephone

**ERICSSON** 

BUSINESSPHONE 250 / BUSINESSPHONE 50 – VERSION 5.0  
BASIC TELEPHONE, DIALOG 3210

## USER'S GUIDE

Copyright © 2000. Ericsson Austria AG. All rights reserved.

This document contains proprietary information which is protected by copyright. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or by any information storage and retrieval system, or translated into another language, without prior written consent of Ericsson Austria AG, Vienna, Austria.

The information in this document is subject to alteration without prior notice.

ERICSSON MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Ericsson shall not be liable for errors contained herein nor for incidental or consequential damages in connection with the furnishing, performance or use of this material.

Ericsson Austria AG  
Pottendorfer Strasse 25-27  
A-1121 Vienna, Austria  
Telephone: +43-1-81 100-5450  
Telefax: +43-1-81 100-5437  
<http://www.ericsson.at>



## CD-ROM

On the CD you will find helpful products and your user's guide in electronical format.

### **Hardware requirements:**

CPU Pentium 166MHz, 32 MB RAM  
15 MB free memory on hard disk (optional)  
VGA 800\*600, 8 bit, 256 colors  
Sound card (recommended)  
CD-ROM drive (12x)

### **Software requirements:**

Operating system: MS Windows 9x, MS Windows 2000 or  
MS Windows NT 4 (service pack 3 or higher)

## **No CD-ROM?**

Please send an e-mail to:  
[businessphone.documentation@sea.ericsson.se](mailto:businessphone.documentation@sea.ericsson.se)  
and we will send you a personal copy for free!

---

## **Designation Card Manager**

The Designation Card Manager is the tool for designing and printing your personal designation cards.

---

## **Also included**

All user documentation as pdf-files, a quick reference help system, a screen saver and a demo version of our BusinessPhone Computer Based Training tool.

Welcome to the User's Guide for the Basic phone in the BusinessPhone 250 / BusinessPhone 50 system from Ericsson.

It is a state-of-the-art business communications system. Its alliance of features and facilities effectively improves communications for virtually any kind of organization.

To take full advantage of these advanced features and facilities there is a line of phones, designed for ease of use in every situation.

*Note: The features described in this user's guide are related to version 5.0 of the BusinessPhone 250 / BusinessPhone 50 system, some features described in this guide might not work in earlier version of the system.*

Some features described in this user's guide might be protected by a hardware dongle that has to be bought separately.

Your phone is equipped with programmable keys for single-key access to frequently used functions and numbers.

The User's Guide describes the facilities of the BusinessPhone system and the Basic phone with a factory defaults programming. There may be some differences in the way your phone is programmed. Please consult your system administrator if you need further information.


Function descriptions that do not include speaking in the handset, are described as off-hook, if nothing else is stated. Instead of pressing the "Clear-key", you can always replace the handset.

*Note: Dialog 3210 is a system telephone, i.e. it can only be used for an Ericsson private branch exchange that supports this type of telephone.*

**Table of Contents**

	page
Description .....	5
Incoming calls .....	7
Outgoing calls .....	8
During calls .....	10
Call forwarding .....	15
Information .....	19
Internal messages .....	23
Mailbox system .....	27
Abbreviated numbers .....	31
Group facilities .....	34
Other useful facilities .....	40
Security .....	47
Least Cost Routing .....	49
Optional equipment .....	50
Programming .....	53
Visible signals.....	56
Audible adjustments .....	57
Tones and signals .....	59
Glossary .....	60
Installation .....	62
Useful hints .....	64
Index .....	65
Quick reference guide .....	67

DESCRIPTION



(continued)

**DESCRIPTION**  
**(continued)**

- 1 Message / Conference**
  - a. To send and receive messages. See section "Internal messages".
  - b. To establish a telephone conference. See section "During calls".
  
- 2 Programmable key / Headset key**
  - a. Storing numbers and program functions.
  - b. The headset function is only available with option unit (DBY 410 02) installed. The headset key is programmed by the system administrator. See section "Optional equipment".
  
- 3 Programmable keys**

Storing numbers and program functions.  
See section "Programming".
  
- 4 Inquiry**

To make an inquiry to an internal or external party.  
See section "During calls".
  
- 5 Line**

Line key for in and outgoing calls.
  
- 6 Volume control**

To adjust the volume. See section "Audible adjustments".
  
- 7 Mute**

To switch the microphone on or off.  
See section "During calls".
  
- 8 Loudspeaker on/off**

To switch the loudspeaker on or off.  
See section "During calls".
  
- 9 Clear**

To disconnect calls.
  
- 10 Loudspeaker**
  
- 11 Handset with hearing aid function**

*Please note: The handset may retain small metal objects in the earcap region.*

## INCOMING CALLS GENERAL

A ringing signal and a flashing lamp indicates an incoming call.

## ANSWER CALLS



### Lift the handset

### On another extension

You can answer a call to another extension from any phone in your office.



### Lift the handset and call the ringing extension

You receive busy tone.



### Press

### A second call is waiting

A muted ringing signal will inform you, during a conversation, that a second call is waiting on your phone.

To answer the second call:



### Press to finish the ongoing call

The new call will be signalled on your phone.



### Press to receive the new call

## OUTGOING CALLS GENERAL

Sometimes you make a call but the person is not available. These functions will help you in your attempts to establish contact with the called party.

## MAKE CALLS

How to make internal and external calls.



**Lift the handset and dial either:**




**An extension number to make an internal call,**

**or**



**The digit(s) for external call access and the external number**

*Note: Which digit to press for external call access, depends on the configuration of the system.*



**To end the call**

*Note: You can make your calls faster, using common abbreviated numbers and by programming your own abbreviated numbers.*

## LAST EXTERNAL NUMBER REDIAL

When you initiate an external call the system automatically stores all the dialled digits, irrespective of whether the call was successful or not.



**Lift the handset and press to redial the last dialled external number**

## SAVE EXTERNAL NUMBER

When you make an external call, you can save the number in order to redial it easily. Previously saved number is erased. Before you finish the call:



**Press to save the dialled number (pre-programmed)**

### Redial number



**Press to redial the saved number (pre-programmed)**

**AUTOMATIC CALL-BACK**

You call an extension and receive busy tone or get no answer.

5

**Press**

Verification tone.



**Press or replace the handset to finish the procedure**

You are called back if the extension finishes the ongoing call or the next time the extension finishes a new call. You have to answer within eight seconds otherwise the call-back service is cancelled.



**Lift the handset when you are called back**

**BUSY EXTENSION**

You call an extension and receive busy tone.

**Camp-on**

You can notify a busy extension of your call by a muted ringing call (if this function is allowed).

4

**Press to camp on**

Keep the handset off hook. When the called extension replaces the handset, it will be called automatically.

*Note: If you receive the busy tone again, the desired extension does not allow camp-on.*

**Intrusion**

You can intrude on an ongoing call on a busy extension (if this function is allowed).

8

**Press to intrude**

Intrusion tone is heard and a three-party call is established. When the called extension replaces the handset and you keep off hook, the called extension will be recalled automatically.

*Note: If you still hear the busy tone, then your extension does not have the authority to intrude or the desired extension is protected against intrusion.*

## DURING CALLS GENERAL

The BusinessPhone 250 / BusinessPhone 50 system allows you to handle calls in many different ways. You can monitor calls, mute the microphones, make an inquiry, transfer the call, create a conference or put the call on hold to perform other tasks.

## MONITORING

You have an ongoing conversation via the handset.



### Press to switch the loudspeaker on

The loudspeaker monitors the call.

*Note: When the loudspeaker is on, the microphone is automatically switched off in the handset. You can adjust the volume, see section "Audible adjustments".*

## From monitoring to handset



### Press to switch the loudspeaker off

Continue your conversation via the handset.

## MUTE

You can turn off the microphone of the handset. Then the caller will not be able to hear the conversation in your room.



### Press to switch the microphone on or off

The lamp lights, if the microphone is turned off.

**INQUIRY**

During an ongoing conversation you like to make an inquiry to an internal or external party.

**Inquiry** 

**Press**

The first call is put on hold (the lamp flashes slowly).



**Call the third party**

When the third party answers you can switch between the calls, create a conference and end one of the calls.

**End inquiry**



**Press to end the inquiry call**

The second call is disconnected.

**Line** 

**Press to retake the first call**

Now you are connected to the first party.

**REFER BACK**

You have an ongoing conversation and want to refer back to the parked call. The lamp flashes at the parked call.

**Line** 

**Press to park the second call**

First call is connected.

**Inquiry** 

**Press to park the first call**

Second call is connected.



**Press to end the ongoing call**

## TRANSFER

You have an ongoing internal or external conversation and you want to transfer an ongoing call.

**Inquiry** 



**Press**

### Call the third party

You can transfer the call before answer or wait for answer

*Note: Make sure, that you are connected to the desired party. Please read the notes and warnings in section "Useful hints".*



### Replace the handset

The call is transferred. External calls might only be transferred with the Transfer-key, if this state of connection is allowed by the system-programming.

---

### Transfer to a busy extension

You can even transfer calls to busy extensions. The other party will hear a muted signal (camp-on), and the call will be extended, as soon as the ongoing call is terminated (if camp-on is allowed).

---

### Call-back

You are called back, if you have transferred an external call and the other extension has not answered the call within a certain time. Your telephone will ring again.

**CONFERENCE**

You have an ongoing conversation and you want to establish a telephone conference.

**Inquiry** 

**Press**



**Call the third party**

**Message/  
Conference** 

**Press**

Now you have established a three party conference. To mark the conference, all conference members will hear a periodical conference tone.

**Repeat the procedure to include other persons to the conference**

In this way, you can include up to six parties in a conversation. How many of them can be external callers depends on the programming of the system.

**INDIVIDUAL HOLD**

You have an ongoing conversation, i.e. the "Line"-key is lit. Now you want to park the ongoing call for a short while.

**Line** 

**Press the line key**

The lamp flashes slowly.

**Line** 

**Press again to retake the parked call**

*Note: This is also valid for the "inquiry"-key.*

## COMMON HOLD

Hold 

### Press (pre-programmed)

The line key lamp flashes slowly. The call can be picked up on any extension within one minute, or else it will recall on the holding extension.

Line 

### Press to pick up on own extension

or

Pick up on another extension:



### Call the extension that put the call on hold



Press

## CALL FORWARDING GENERAL

When you are not available to take calls or decide to answer your calls on another extension, it is useful to forward your calls to an alternate answering position. If you urgently need to talk to someone who has forwarded his calls, the system is also equipped with a bypass function.

Depending on the type of diversion you are also able to record your personal greeting, see section “Personal greeting”.

*Note: You can still make calls as usual.*

---

### Diversion on no reply

If you are not available to answer incoming calls (internal or external), your system administrator can program your extension to automatically divert calls to a programmed diversion address (default time: 15 seconds).

---

### Diversion on busy

If your extension is busy and you receive an incoming call (internal or external), your system administrator can program your extension to automatically divert the call to a programmed diversion address.

---

## FIXED DIVERSION

This function directs your calls to a pre-programmed answering position (e.g. secretary).

---

### Activate fixed diversion



**Press to activate diversion**



**Press**

---

### Cancel diversion



**Dial to deactivate fixed diversion**



**Press**

## INDIVIDUAL DIVERSION

This feature gives you the possibility to divert your calls to internal and external positions, e.g. to any directory number, a colleague's extension, an external number or a common abbreviated number (e.g. your car telephone).

*Note: In order to prevent misuse, individual external diversion can be blocked for your extension, see section "Security".*

---

### Program and activate internal diversion



Divert your calls to an internal position.

**Dial**



**Enter the new diversion address**



**Press to active the individual diversion**

Verification tone.



**Press to finish the procedure**

You can make outgoing calls as usual.

A special dial tone reminds you that "Call forwarding" is active.

*Note: An individual internal diversion cannot be activated if an individual external diversion is already activated.*

---

### Cancel internal diversion



**Dial**



**Press**

## Program and activate a new external diversion address



To set a new individual external diversion address:

**Dial**



**Dial the digit(s) for external call access and enter the new external diversion address**

A maximum of 24 digits.



**Press to activate the individual diversion**

Verification tone.



**Press to finish the procedure**

*Note: Individual external diversion can also be used via the DISA function, see section "Other useful facilities".*

---

## Cancel external diversion



**Dial**



**Press**

*Note: The programmed diversion address is not removed from the memory, the diversion is just inactive.*

---

## Re-activate external diversion



Divert your calls to an external position.

**Dial to activate the programmed external diversion**

You can make outgoing calls as usual. A special dial tone reminds you that "Call forwarding" is active.



**Press**

## FOLLOW ME

If you are in another room, you can still answer your calls by forwarding them to where you are. To activate Follow me, "Individual Diversion" must be active on your telephone.

### Activate Follow me

*Note: This procedure has to be executed from the telephone the calls are diverted to.*



**Dial**



**Dial your number and press**



**Dial the new number and press**

Special dial tone.



**Press to finish the procedure**

### Cancel Follow me

Follow me and individual diversion can also be cancelled from the answering position.



**Dial**



**Dial your number and press**

Dial tone.



**Press to finish the procedure**

## BYPASS CALL FORWARDING

Bypass call forwarding makes it possible to call a specific extension, even if call forwarding is activated on this extension.



**Lift the handset**



**Press**



**Enter extension number and press**

You will be connected to the specified extension, regardless of which type of call forwarding the called extension has activated.

## INFORMATION GENERAL

If you are not in the office for a certain period of time (e.g. meeting, vacation, lunch, illness), this feature allows you to inform your callers why you are absent. External callers will be routed to the operator who also has access to your absent info.

*Note: When you have activated a diversion with a personal greeting, callers will receive this greeting instead of your activated absence information.*

You can inform your callers with:

### 1) Pre-defined texts

Enter the reason for your absence and the date and time of your return.

### 2) Voice information

Record a voice message and name your absent information.

---

## ENTER INFORMATION

To store text or voice information.



**Press to enter the information mode**

**Select "Pre-defined text" or "Voice information"**

(continued)

## ENTER INFORMATION (continued)

### Pre-defined texts



Enter "Code" and



Enter "Completing info" from the table below

	Code	Completing info
Time of return	1	hour (00-23) minute (00-59)
Date of return	2	month (01-12) day (01-31)
Lunch	3	back at, hour minute
Meeting	4	back at, hour minute
Vacation	5	back, month day
Illness	6	back, month day



Press to enter the information




Press to finish the procedure

Internal callers receive the information on the display (or as spoken information to callers without display phone).

### Pre-defined texts

Example:



*Vacation, back June 27*

If you do not know the time of return, just press #. Information active. Internal callers receive the information on the display (or as spoken information to callers without display phone). External callers will be routed to the operator who also has access to your absent info.

## Voice information



**Press to enter information mode**



**Press and speak**



**Press to play-back and listen to your recording**



**Press and speak to re-record**



**Press to send**

Information active.



**Press to finish the procedure**

Internal callers will hear the information via the handset or the loudspeaker. External callers will be routed to the operator who also has access to your absent info.

*Note: You can dial your own extension number if you want to check your information.*

## ERASE INFORMATION, SAVE INFORMATION



**Press to erase info**

**or**



**Press to deactivate and save for later use**

Information is passive.



**Press to finish the procedure**

---

## Use saved information

When the information is switched off:



**Press to activate saved info**

Information is active.



**Press to finish the procedure**

## INTERNAL MESSAGES

### GENERAL

You can send a call-back or a voice message when you call an extension and receive busy tone or get no answer. This section also describes how to record an ongoing conversation and a personal voice message. Your incoming messages are indicated on your telephone by a rapidly flashing "Message/Conference"-key.

### SEND MESSAGE

To send a message to an extension when you receive busy tone or get no answer.

#### Call-back

To send a "call me" message.

*Message/  
Conference*



**Press**



**Press to send**

#### Voice

To send a voice message.

*Message/  
Conference*



**Press**



**Press and speak a voice message**



**Press to play-back and listen to your recording**



**Press and speak to re-record**



**Press to send**

## CHECK AND STORE RECEIVED MESSAGES

You can check and store your received messages.

Received messages are divided into following three categories:

- New messages (not heard or read)
- Heard/Read messages
- Stored messages

*Note: Messages are deleted from the system after a certain time. The time depends on which category the message belongs to. Please ask your system administrator regarding this.*

**Message/  
Conference**



### Press to view mailbox

If the mailbox contains heard messages only, the lamp shows steady light instead. You can check and store your received messages. Up to 20 messages can be stored.

Voice messages will be heard via the speaker or the handset. "Call me" messages will call the sender automatically (these messages cannot be stored).

*Note: Depending on the configuration, you might be asked for your password before you can retrieve your messages. See section "Security".*



### Press to finish the procedure

## DICTAPHONE

If you want to record and retrieve personal voice messages you can use the dictaphone. A dictaphone message is treated as a normal message. How to retrieve dictaphone messages, see section “Check and store received messages”.

---

### Record message

To start the recording:



#### Dial and record your message

The maximum recording time is four minutes and 15 seconds.

Select options below:



**Press to play-back**



**Press and speak to re-record**



**Press to stop the recording and save the message**


## CONVERSATION RECORDING

The conversation recording function makes it possible to store the ongoing telephone conversation in the individual mailbox by pressing a pre-programmed recording key. You can store both internal and external calls. Conference calls cannot be stored.

A recorded conversation is treated as a normal voice message. How to retrieve conversation recordings, see section “Check and store received messages”.

*Note: This feature may be restricted or not available. Ask the system administrator for the availability and for more information. Furthermore, a conference tone can be audible during the entire recording.*

To start or stop recording the ongoing call:

Recording 

### **Press the recording key (pre-programmed)**

While recording is active a steady light indicates that the conversation is being recorded. You can start or stop the recording whenever you want. The maximum recording time is four minutes, if you want to record a conversation longer than four minutes, just repeat the procedure. To program the key, see section “Programming”.

### **Warning!**

Recording a conversation without prior notice to the other party may be an illegal act. Forwarding or playback of this recorded conversation to a third party without prior permission may be an illegal act.

It is obligatory for the recording initiator, to ask the other party in advance for permission and to inform the same of the purpose and further usage of this particular recording. The adherence to the relevant legislation is the exclusive responsibility of the user, offences can be criminally prosecuted. Neither the manufacturer nor the dealer of this product is responsible for the abuse of this feature by the user or for any damages caused thereby.

## MAILBOX SYSTEM GENERAL

While you are away from the office, callers can leave messages in your individual or in a common mailbox. You are also able to record your personal greeting, see section “Personal greeting”.

The difference between your individual mailbox and a common one is that a common mailbox can be used for more than one user.

## INDIVIDUAL MAILBOX SYSTEM

Callers are able to leave messages in your individual mailbox.

### Activate

Divert your extension to the mailbox system.



**Press**



### Dial the number to the mailbox system

Ask the system administrator for your defined mailbox number.



**Press**



### Press to finish the procedure

When the diversion to your mailbox is activated, the Diversion lamp shows steady light.

### Deactivate



**Press**



**Press to finish the procedure**

(continued)

## INDIVIDUAL MAILBOX SYSTEM (continued)

### Retrieve messages - internally



*Message/Conference*



When a new message is received, the message lamp flashes rapidly.

#### Lift the handset

#### Press to retrieve a message

See section “Check and store received messages”.

### Retrieve messages - externally



To retrieve your messages from an external position:

#### Lift the handset and dial your company’s telephone number

#### Dial the number to the mailbox system

During the procedure you will be asked for your extension number and your password.

## COMMON MAILBOX SYSTEM

### Activate



Callers are able to leave messages in the common mailbox.

Divert your extension to the mailbox system.

#### Press

#### Dial the common mailbox number

Please ask the system administrator for your defined mailbox number.

#### Press

#### Press to finish the procedure

When the diversion to your mailbox is activated, the Diversion lamp shows steady light.

**Deactivate****Press****Press to finish the procedure****Retrieve messages - internally****Lift the handset***Common mailbox***Press the common mailbox key (pre-programmed)**

During the procedure you will be asked for your extension number and your password. See section "Security".

**Retrieve messages - externally****Lift the handset****Dial your company's telephone number****Dial the common mailbox number**

During the procedure you will be asked for your extension number and your password.

## PERSONAL GREETING

Depending on the type of diversion you want to activate, you can leave three different personal greetings to the caller. The diversion state can be on no reply, on busy or an activated individual diversion.



### Lift the handset



### Dial

During the procedure you will be asked for your extension number and your password.



### Press to configure your personal greeting



### Enter diversion code

Select an option below and follow the voice announcements.

<i>Type of diversion</i>	<i>Code</i>
Diversion greeting on busy	1
Diversion greeting on no reply	2
Individual diversion greeting	3



### Press to store the recorded greeting

When you activate the diversion, the recorded greeting is played to the next caller.



### Press to finish the procedure

*Note: When you have activated a diversion with a personal greeting, callers will receive this greeting instead of your activated absence information.*

**ABBREVIATED  
NUMBERS GENERAL**

By using abbreviated numbers, you can make calls simply by pressing a few keys.

Frequently used external numbers are stored as "common abbreviated numbers" in the exchange.

10 "individual abbreviated numbers" (your personal most frequently used external numbers) can be stored and used on the keys "\*\*0" to "\*\*9".

**COMMON  
ABBREVIATED  
NUMBERS**

External numbers are stored centrally in your BusinessPhone system. Common abbreviated numbers have a maximum of 4 digits and can be dialed from every extension that has the authority to do so.

**Lift the handset****Dial the common abbreviated number**

Please refer to your telephone directory.

**DIAL-BY-NAME**

You can program and activate directory numbers (extensions and common abbreviated numbers) on the programmable keys. If you have programmed a number on a programmable key, you just have to press this key to call the desired person.

**Lift the handset**

*Michael P.*

**Press to make a call (pre-programmed)****(continued)**

## DIAL-BY-NAME (continued)

**Program dial-by-name** How to program an internal directory number on a programmable key.



**Enter programming mode**



**Press a programmable key**



**Press**



**Press the programmable key again**



**Dial the number**

You can use any directory number, e.g. a common abbreviated number or a colleague's extension number.



**Press the programmable key again**



**Press to finish the procedure**

## INDIVIDUAL ABBREVIATED NUMBERS

You can program and activate your most frequently used external numbers on the keys "\*\*0" to "\*\*9".



**Lift the handset and press**



**Dial the abbreviated number**

A number between 0 and 9.

## Program individual abbreviated number

How to program external numbers on the keys 0 to 9.



**Enter programming mode**



**Select an abbreviated number between 0 and 9 and press**



**Dial the external number and press**

The number can consist of up to 24 digits.



**Press to finish programming**

---

## Cancel one specific individual abbreviated number



**Press**



**Enter an abbreviated number between 0 and 9**



**Press**

---

## Cancel all individual abbreviated numbers



**Press**

Confirmation tone.

## GROUP FACILITIES GENERAL

When you are working together in a team the following group facilities can be very useful. You can page your colleagues, give them telephone attendance or pick up their incoming calls.

## LOUDSPEAKER PAGING

You can page all extensions in a group and give a voice message.



**Lift the handset**



**Press (pre-programmed)**

All extensions in a group are called.



**Press again and hold the key (pre-programmed)**

Give the voice message and then release the key.

Now you can wait for answer, or terminate. If you do not get an answer within 30 seconds, the paging function will be terminated automatically.

## Answer paging

A short signal and a flashing "Paging"-key will inform you when a loudspeaker paging is received.



**Lift the handset**



**Press (pre-programmed)**

An internal call is established with the paging party.

## KEY SYSTEM

With this function, all (or selected) external lines are represented by pre-programmed keys on all phones. For each external line, a function key has to be programmed. Which means that you are able to monitor the state of traffic for every programmed external line (e. g. free, busy). You can also establish an external call by pressing the external line key.

### Answer an external call



To answer an external call, just press the flashing key. (Depending on the programming of the system, an incoming external call will be announced with a flashing line-key and a ringing signal).



#### Lift the handset

#### Press (pre-programmed)

Speech connection with the caller.

### Make an external call



To initiate an external call, just press the external line key. The external line will be seized automatically.



#### Lift the handset

#### Press a free line-key (pre-programmed)



#### Dial the desired number

If you make external calls in this way, you do not have to dial the digit(s) for external call access first.

## SUPERVISION/ TELEPHONE ATTENDANCE

A function-key can also be programmed for supervision and handling calls for a group of extensions. If a supervision/attendance-key is programmed on your telephone, you are able to call the other group-members or answer incoming calls for the group by pressing the key and monitor the activity of other extensions (free, busy, called).

---

### Traffic situation

Michael 

**Ongoing conversation (lamp is on)**

Michael 

**Free extension (lamp is off)**

Michael 

**The extension is called (flashing lamp)**

---

### Pick-up calls for the group



**Lift the handset**

Your colleague's extension is indicated on your phone by a pre-programmed key.

Michael 

**Press to answer the calls directly  
(pre-programmed)**

A flashing lamp beside the key indicates an incoming call.

---

### Call a group-member



**Lift the handset**

Michael 

**Press to make the calls directly  
(pre-programmed)**

*Note: If the key is flashing, you will automatically pick-up your colleague's ongoing call.*

## GROUP HUNTING

Your telephone can be included in one or several hunt groups. In a hunt group all members are represented with one common directory number. 16 hunt groups can be programmed, each containing 1 to 20 members. A member can be either an extension number, an operator console or a fictive number. Please ask your system administrator if you require this function.

*Note: The number of cordless extensions in a hunt group are limited to eight (including tandem configurations).*

Incoming calls to the hunt group are directed to free extensions in the group. The hunt order within the group can be changed to suit your needs. If no one answers an incoming call before the programmed time, the call is forwarded to the programmed answering position (e.g. operator).

*Note: If all members in a hunt group are busy, the call-back or intrusion functions are not available, however the camp-on function can still be used.*

---

### Log in

⊛ 2 8 ⊛

Before you can answer group hunting calls, you must log in.

To log in to one hunt group:

**Dial**

○ ○ ○ ○ ⊛

**Dial the hunt group code and press**

Please ask your system administrator for the configured number.

To log in to all hunt groups:

⊛ 2 8 ⊛

**Dial**

⊛ ⊛

**Press**

(continued)

## GROUP HUNTING (continued)

### Answer calls

Answer group hunting calls in the normal way.

---

### Log out



To log out from one hunt group:

**Dial**



**Dial the hunt group code and press**

Please ask your system administrator for the configured number.

To log out from all hunt groups:



**Dial**



**Press**

---

## GROUP CALL PICK UP

In a Pick up group, any member can answer any individual call to group members. You answer a call to the group by dialling a special answering number. Please ask your system administrator for the configured number.



**Lift the handset**



**Dial the group call pick up code**

## COMMON BELL



The common bell facility allows all extensions of the system (operator included) to pick up the call from an extension that has been predefined as a common bell extension.

### **Dial the common bell pick up code**

Please ask your system administrator for the common bell pick up code.

### **Lift the handset**

You will immediately be connected with the calling party.

If two or more extensions simultaneously attempt to answer a call from the common bell extension, only the first extension will pick it up. The other extensions will receive the "number unobtainable" tone.

This will also happen if you dial the common bell pick up code and there are no calls waiting at the common bell extension.

*Note: You can also program the common bell code on a function key.*

### OTHER USEFUL FACILITIES GENERAL

By using these facilities your productivity will be increased, e.g. you can set reminders for important meetings, place the costs for external calls on separate accounts, listen to music via the loudspeaker and much more...

### REMINDER

The phone can be set to remind you at any time within the next 24 hours (multiple settings are allowed).



#### Dial



#### Dial reminder time and press

(00-23) hour + (00-59) minute. Delete the at last entered digit with the "minus" -key.

*Note: If you receive busy tone, your extension does not have the authority to set a reminder.*



#### Press to finish programming

When the reminder time is reached, your phone rings with recall signal.

### Cancel reminder



#### Dial to cancel all settings



#### Press to finish the procedure

**ACCOUNT NUMBER**

You can place the costs for external calls on a selected account number (up to 15 digits).

**Enter account number before the call**

**Lift the handset**



**Dial**



**Enter account number and press**

Internal dial tone. Make the external call.

**Enter account number during the call**

If your telephone has a pre-programmed account number-key, you can also enter an account number during a call.

*Account number* 

**Press (pre-programmed)**



**Enter account number and press**

**AUTOMATED ATTENDANT**

The Automated Attendant facility sends voice instructions to external and internal callers, informing them of all possible options they can choose. Voice instructions lead the callers step by step to the desired destination.



**Lift the handset**




**Dial the Automated Attendant directory number**

Please ask your system administrator for the Automated Attendant directory number.

### BACKGROUND MUSIC

You can listen to background music over the loudspeaker on your phone by pressing a pre-programmed Music key, or by entering the number for the music channel. Please ask your system administrator for the configured number.

*Background music* 

#### **Press to activate the music (pre-programmed)**

The music automatically switches off when you make or receive calls and switches on again when the call is finished.



#### **Press to cancel the music**

*Note: You can adjust the volume, see section "Audible adjustments".*

### INTERCOM LINE

A two-way direct call function between two extensions, for instance in executive-secretary communication.



#### **Lift the handset**

*Intercom to Secretary* 

#### **Press to establish an intercom call (pre-programmed)**



#### **Press to cancel the intercom call**

### NIGHT SWITCHING

If you want this facility, please ask your system administrator. This function is used for directing all incoming calls to one extension (answering position), for example when the office is closed.

*Night* 

#### **Press to activate or deactivate (pre-programmed)**

When the lamp lights, night switch is active. When the lights extinguishes, night switch is passive.

## TANDEM CONFIGURATION

The tandem configuration is a unit, consisting of two telephones using the same directory number. One of the telephones is defined as the "Primary" and the other one as the "Secondary".

This function enhances the communication for users that, for example, have a wired phone on their desk (the "primary telephone") and need to be mobile within their company's building with their own portable (the "secondary telephone"). Basically the tandem configuration works as follows:

### To activate the tandem configuration

*Secondary on/off* 



**Press (pre-programmed)**

or

**Dial to log on the secondary telephone**

For incoming calls:

- Both telephones are treated as 1 single extension.

For outgoing calls:

- Both telephones are treated as 2 separate extensions.

### To deactivate the tandem configuration

*Secondary on/off* 



**Press (pre-programmed)**

or

**Dial to log off the secondary telephone**

For incoming calls:

- The "secondary" telephone cannot be called and the "primary" telephone works as a normal "stand-alone" telephone.

For outgoing calls:

- Both telephones are treated as 2 separate extensions.

**(continued)**

### TANDEM CONFIGURATION (continued)

#### Transferring a call between the members of a tandem unit

*Inquiry*



**Press and dial own directory number**

*Transfer*



**Press (pre-programmed)**

**or**



**Go on-hook**

### DIRECT INWARD SYSTEM ACCESS (DISA)

If you are working externally and you have the need to make business calls, call your company and use the company PBX to make an external call to the desired party. You just pay the costs for the phone call to your company. The other costs will automatically be placed on your extension number or on a special project.

*Note: To activate this function, you have to change the default password from "0000" to a personal one. Which code to use and how to change it, see section "Select password".*

You can also divert calls from your office extension to your external position, see section "Call forwarding".

During the procedure you will be prompted for your password. See last page for a card to remember these specific numbers.



**Lift the handset and dial the public number of  
your company**



### followed by the DISA number

Please ask the system administrator for the defined DISA number.



### Dial the external number

or

### Use the external diversion function

Procedure, see section “Call forwarding”.

*Note: If you program a new diversion address, remember to re-set it when you return to your office.*

## DOORPHONE

The doorphone is used to monitor the admission to your company, i.e you can open the doorlock from your phone.

### Answering door- phone calls



### Lift the handset

You will be in speech connection with the calling party.

### Opening of the doorlock

After you have answered the doorphone, you can open the door making an inquiry to the door-opener's directory number.

**Inquiry** 

### Press



### Dial the door-opener's directory number

Please ask your system administrator for the number.

*Note: You can also program the door-opener's directory number as a common abbreviated number or a function key.*

### NETWORKING

Networking is the connection of several premises within a company. The connection can be set up via leased lines, public lines, Local Area Network (LAN) or Wide Area Network (WAN). Ask your system administrator about details regarding networking.

### IP CALLS

IP calls are internal calls sent via an internal data network (LAN or WAN) and the transfer of data and voice is made on the same line. If you are connected to an internal data network the IP connection is made automatically. To minimise the traffic on the network the speech quality is decreased.

If the speech quality is not acceptable you can disconnect the IP call and switch to a non-IP call (alternative network). The switch from the IP net to the non-IP net is made during the call, so the call does not have to be disconnected.

If you want to switch to a non-IP net during the call:

**Inquiry** 

**Press**

**Dial**

During the procedure the other party is put on hold. When the procedure is ready you will receive a special ringing tone and the call is resumed in the non-IP net.

*Note: A switch to a non-IP call can only be performed if the original call is an IP call, otherwise you will receive a blocking tone.*

## SECURITY GENERAL

You can block your extension in order to prevent unauthorized use of your telephone, e.g if your external calls are placed on a specific account number.

### BLOCK EXTENSION



#### Dial to block your extension

Verification tone.



#### Press to finish the procedure

### Un-block extension



#### Dial



#### Dial your password and press to re-open

Verification tone. Your extension is open for use.



#### Press to finish the procedure

## SELECT PASSWORD

You can use your four-digit password for blocking your phone from unauthorized use, or for making external calls from any blocked extension.



#### Dial to select a new password



#### Dial your present password and press

The default password is "0000".



#### Dial your new password and press

Verification tone.



#### Press to finish the procedure

## BYPASS BLOCKED EXTENSION

In order to make a call, you can temporarily bypass a blocked extension.

### Bypass own extension



**Lift the handset**



**Dial**



**Dial your password and press**

Dial tone. You can make one call from your extension.

### Bypass another extension



**Lift the handset**



**Dial**



**Dial your password and press**



**Dial your extension number and press**

Dial tone. You can make one call from the blocked extension.

## LEAST COST ROUTING GENERAL

Least Cost Routing (LCR) automatically selects the cheapest way to establish the connection to the desired external number. Please ask your system administrator if this function is installed in your system.

## LEAST COST ROUTING

If the extension has been configured to use LCR, each external call will be analysed and the cheapest way will be selected.

### Use least cost routing



**Lift the handset**



**Dial the digit(s) for external call access and the external number**

The usual way of making an outgoing external call.

### Calling least cost routing

If LCR has been installed in your system, but your extension is not configured to use it automatically, you also have the opportunity to get the cheapest connection by dialling the LCR code before you dial an external number.



**Lift the handset**



**Dial the LCR code**

Please ask your system administrator for the LCR code.



**Dial the digit(s) for external call access and the external number**

*Note: You can also program the LCR code on a function key.*

### OPTIONAL EQUIPMENT GENERAL

This chapter describes optional features that can be used together with your BusinessPhone telephone.

---

### OPTION UNIT

The Option unit DBY 410 02 is an optional accessory, to be installed on the bottom of your telephone set. The following devices can be installed via the Option unit:

- Tape recorder
- Extra bell or busy indication outside your door
- Enhanced headset functionality or a conference unit  
*Note: Regarding the headset functions see previous section.*
- PC sound card
- Second handset

*Note: For people with impaired hearing the Option unit offers the possibility to amplify the receiving volume in the handset and headset.*

---

### EXTRA HANDSET

Useful for involving a second person in your conversation, for talking or just listening.

---

### TAPE RECORDER

When a recording of the telephone conversation is needed, for evidence purposes, a tape recorder can be connected.

**HEADSET**

The following headset functions are available.

*Note: To use the headset functions your telephone has to be equipped with option unit DBY 410 02. How to install the option unit, see separate installation instructions provided with the option unit.*

**Activate/Deactivate the headset**



**Press the headset key to activate/deactivate the headset (pre-programmed)**

See section "Description". All calls can be handled via the headset.

**Answer calls**



**Press the flashing line key to answer**



**Press to terminate a headset call**

**Make calls**



**Dial the number**



**Press to terminate the call**

**Headset to handset**



**Lift the handset**

**Handset to headset**



**Press the headset key (pre-programmed)**

### **CONFERENCE UNIT**

For conferences with many participants, the conference unit enhances the speech quality. It provides full duplex and high quality conversation possibilities.

---

### **ALARM INTERFACE UNIT**

This plug-in module is fitted into the bottom of the telephone. It makes it possible to transfer alarm signals from various devices via the telephone to the exchange and to a pre-defined extension. A special circuit layout provides maximum functional security.

To a telephone fitted with an alarm interface unit you can connect devices such as bathroom alarms for hotel rooms, emergency alarms for hospitals, bank security alarms and supervision of machines.

## PROGRAMMING GENERAL

If you require frequent use of certain facilities, you may program them on the programmable keys on the telephone. When you want to use the function, just press the key.

*Note: Programming of dial-by-name keys and individual abbreviated numbers are described in section "Abbreviated numbers" and how to program a new diversion address is described in section "Call forwarding".*

## PROGRAMMING

How to program a function on a programmable key:



**Enter programming mode**



**Press the desired programmable key**



**Select function code**

See section "Function codes and required data".



**Press the programmable key again**



**Enter associated number**

See section "Function codes and required data".



**Press the programmable key again**

**Continue with section "select ringing character"**

or



**Press to finish programming**

After approximately 10 seconds, the function key is active.

(continued)

## PROGRAMMING (continued)

### Select ringing character



#### Select ringing character (0-4)

See section "Function codes and required data".



#### Press the programmable key again



#### Press to finish programming

After approximately 10 seconds, the function key is active.

Example :



#### Enter programming mode

Program supervision of extension 204 on a programmable key, with ringing function 1.



#### Press the desired programmable key



#### Select function code



#### Press the programmable key again



#### Enter extension number



#### Press the programmable key again



#### Press



#### Press the programmable key again



#### Press to finish programming

**FUNCTION CODES  
AND REQUIRED DATA**

Programming name	Function name	Function code	Associated number	Ringling character
NAMECALL	Dial-by-name	10	Extension number	—
SUFFIX DIGIT	Camp-on	11	4	—
	Automatic callback	11	5	—
	Answer calls, another extension	11	6	—
	Radio paging	11	7	—
	Intrusion	11	8	—
EXTERNAL LINE SUPERVISION	External line	12	Directory number of line	0-4
	Supervision/Telephone attendance	13	Extension number	0-4
DEDIC. LINE	Intercom line	14	Extension number	0-4
VOICE PAGING	Loudspeaker paging	15	Number of group (0-7)	—
COMM. MAILBOX	Common mailbox	18	Common mailbox no.	—
SUPERV. SLAVE	Supervision secondary	19	—	0-4
R-KEY	R-key	25	—	—
BUSY LINE 2	Free on 2nd access	26	—	—
CONFERENCE	Conference	27	—	—
IMMED. ANSWER	Immediate answer	28	—	—
ACCOUNT CODE	Account number	30	—	—
OPERATOR HOLD	Operator hold	33	—	—
EXT. VOICE M.	External voice mail	34	—	—
HOLD	Hold	35	—	—
TRANSFER	Transfer	36	—	—
SAVE	Save/Redial	37	—	—
READ &	Read &	38	—	—
* —	* Enter key	39	—	—
NUMB SECRECY	Number secrecy	40	—	—
MALICIOUS-ID	Malicious call identification	41	—	—
LOG ON/OFF SLV	Tandem configuration	43	—	—
CONV. RECORD	Conversation recording	45	—	—

\* Function cannot be programmed via individual programming.

Ringling character:

0 =No ringing.

1 =Ringling.

2 =Delayed ringling (after 10 seconds).

3 =One single ringling signal (muted signal).

4 =One delayed ringling signal (after 10 seconds. Muted signal).

*Note: Accessible functions, depends on the programming of the system.*

## VISIBLE SIGNALS GENERAL

The key lamps on your telephone indicates with different signals the traffic state of the ongoing call or function.

## LAMP INDICATIONS



Extinguished lamp

The function is not active.



Steady light

The function is active.



Slowly flashing lamp

The line (or function) is put on hold.



Rapidly flashing lamp

An incoming call or message waiting.



Light with short breaks

Ongoing call.

## AUDIBLE ADJUSTMENTS GENERAL

In order to satisfy your personal needs, the BusinessPhone 250 /50 BusinessPhone system is equipped with many options to set and adjust a personal volume and ringing signal.

## HANDSET AND LOUDSPEAKER VOLUME

Use the volume keys. You can set different volume levels for internal and external calls and for background music. During a call, adjust handset listening volume in handset mode. Adjust loudspeaker volume in monitor mode or during background music.



**Press to change the volume**

## RINGING SIGNAL

By programming, you can adjust ringing type (2 types), ringing volume (10 steps) and ringing character (10 characters).



**Enter programming mode**

Now you can select ringing type, volume or character.

### Ringing type

Select type 1 if you want the set ringing volume at a constant level, select type 2 if you want gradually increasing volume when the phone rings.



**Press**

**or**



**Press**

You will hear the selected type.



**Press to finish the procedure**

*Note: When type 2 is selected, the programming of the ringing volume is not applicable.*

(continued)

## RINGING SIGNAL (continued)

### Ringing volume

2 \* 0 — 9

#### Press

You will hear the selected volume (0...lowest volume, 9...highest). You only have to press the last digit to select another ringing volume.



#### Press to finish the procedure

*Note: This programming is not applicable when you have selected ringing type 2.*

### Ringing character

3 \* 0 — 9

#### Press

You will hear the selected character. You only have to press the last digit to select another ringing character.



#### Press to finish the procedure

**TONES AND SIGNALS**

Tones are audible in the handset. Ringing signals are emitted from the phone. You can adjust the tones and signals on your phone. See section "Audible adjustments".

**Dial tone**

(System ready to accept digits)



**Special dial tone**

(System ready to accept digits, active diversion on telephone)



**Ringing tone**

(Ringing signal to called party)



-repeated after 4 s

**Special ringing tone**

(Ringing signal to line 2)



-repeated after 4 s

**Busy tone**

(Called party is busy)



**Number unobtainable tone**

(Called number not accessible or vacant)



**Blocking tone**

(Call cannot be executed due to congestion or called party blocked)



**Verification tone**

(Verification that ordered function is accessed)



**Intrusion tone**

(Sent to all parties during intrusion)



**Conference tone**

(Sent to all participants in a conference)



-repeated after 15 s

**Internal ringing signal**




-repeated after 4 s

**External ringing signal**



-repeated after 4 s

**Automatic call-back signal**



*Note: The tones and ringing signals in this guide refer to the standard system but may vary between countries.*

## GLOSSARY

### ABBREVIATED NUMBER DIALLING

Initiating a call to a pre-programmed number by dialling a code or pressing a key. Short numbers can be: *1. Common, which means that all extensions can use them.* *2. Individual, which means that they are programmed and used by each extension separately (10 numbers).* See section "Abbreviated numbers".

### ACCOUNT NUMBER

To place costs for external calls on a selected account number (up to 15 digits). See section "Other useful facilities".

### AUTOMATED ATTENDANT

A facility which sends voice instructions to internal and external callers, providing all options which can be chosen. Voice instructions lead the caller to the desired destination. See section "Other useful facilities".

### CALL-BACK

An indication to a busy extension, to inform the person that you want to speak to him/her. See sections "Internal messages" and "Outgoing calls".

### CAMP ON

To place (queue) a call to a busy extension. See section "Outgoing calls".

### COUNTER

The counter keeps track of the time and cost of your calls. See section "Call metering".

### DIAL-BY-NAME

Initiation of a call by operating a single key. Internal numbers (or common abbreviated numbers) can be stored on each extension. See section "Abbreviated numbers".

### DIRECTORY NUMBER

Numbers with 1-8 digits which are assigned to extensions or external lines or as common abbreviated numbers.

### DIRECT INWARD SYSTEM ACCESS (DISA)

If you are working externally, the DISA function enables you to make external calls (long distance) via the company PBX. You only pay for the call to your company. See section "Other useful facilities".

### DIVERSION

Incoming calls to an extension are diverted to another directory number (extension, common abbreviated number or the operator). There are three possibilities: *1. Direct, which means that all calls to an extension are forwarded directly.* *2. On no reply, which means that a call is forwarded if it is not answered within a certain time.* *3. On busy, which means that a call is forwarded if the extension is busy.* See section "Call forwarding".

### DIVERSION BYPASS

This is useful for letting urgent calls through to an extension where diversion is active. See section "Call forwarding".

### EXTENSION

All telephones connected to the PBX have a unique internal number (upto 3 digits).

### FUNCTION CODE

A two digit code that corresponds to a specific function. See section "Programming".

### HOLD

To park a call. See section "During calls".

### INFORMATION

Internal callers are informed about absence and time of return. External callers are diverted to the operator, where the same information is available. Information can be of two kinds: *1. Pre-programmed text information.* *2. Voice information.*

### INTERCOM LINE


A two-way direct call function between two extensions, for instance an executive-secretary communication. See section "Other useful facilities".

### INTRUSION


To intrude on an ongoing call when a requested extension is busy. See section "Outgoing calls".

<b>IP CALL</b>	Internal call sent via an internal data network (LAN or WAN).
<b>ISDN</b>	Integrated Services Digital Network. Provides your system with supplementary services from the public net.
<b>LEAST COST ROUTING</b>	A function that automatically selects the cheapest way to connect your external call (not necessarily the shortest distance). See section "Least cost routing".
<b>LOUDSPEAKER PAGING</b>	All members of an extension group are "paged", i.e. receive a short, sharp tone on the loudspeaker followed by a voice message from the sender. See section "Group facilities".
<b>MAILBOX</b>	The mailbox system controls the messages that are left for or sent by you when you are absent. See section "Mailbox system".
<b>MESSAGE</b>	A message can be sent to any extension. This is useful when you receive the busy tone or get no answer. There are two kinds of message: 1. "Call me" message. 2. Voice message. See section "Internal messages".
<b>MUTE</b>	To switch the microphone temporarily off. See section "During calls".
<b>NIGHT SWITCHING</b>	Used for directing all incoming calls to one extension (answering position), for example when the office is closed. See section "Other useful facilities".
<b>PASSWORD</b>	A four-digit code needed to e.g. block your extension and retrieve messages from the mailbox system. You can set your own password. See section "Security".
<b>PBX</b>	Public Branch Exchange. Your telephone switching system (e.g. BusinessPhone 250).
<b>PRE-DEFINED TEXT</b>	Pre-programmed absent information. See section "Information".
<b>THIRD PARTY</b>	A third connection (person), which can be included in an ongoing two person conversation. The connection can be internal or external. See section "During calls".
<b>TIE LINE</b>	An external line from the private network.
<b>TRANSFER</b>	During an internal or external ongoing call you can make an inquiry and then transfer the call to another party (internal or external). See section "During calls" and "Useful hints".
<b>TRUNK LINE</b>	A trunk line is the same as an external line. Can be either digital or analogue.

## INSTALL STAND




## INSTALL CABLES



- 1 Cable to handset
- 2 Cable to exchange
- 3 Space for personal number directory (optional)
- 4 Wallmounting screw holes

Wall  
mounting  
handset  
hook



You can put the cable to the handset in any of the two notches underneath the telephone. The cable to the exchange has to be plugged in "LINE".


## Change cables

To remove a cable, push down the plug's stop. Use a screw-driver to unlock the stop.

## PLACING THE TELEPHONE

- Do not place your telephone on sensitive surfaces. Use a non-slippery pad to protect your furniture from possible damage.
- Do not place your telephone near sources of extreme heat, e.g. near the radiator.
- Make sure that the line cable isn't creased.

## ADJUST TELEPHONE



## CLEANING THE TELEPHONE

Use a slightly moistened (not wet) cleaning-rag or an anti-static rag and wipe off the telephone carefully. Do not use rough rags, solvents or aggressive cleaning fluids. Any damages of the telephone, that are caused by non-observance of these instructions, are not part of the liability given by the manufacturer.

### CONNECTIONS BETWEEN EXTERNAL LINES

With your BusinessPhone PBX, you can establish an external call diversion or a conference with more than one external party or transfer an external call too another external destination (e.g. a mobile phone). These features are very useful for everyday business life.

*Note: When these features are used, your BusinessPhone will occupy at least two external lines.*

However, there may be disadvantages in connecting to several external lines. We would therefore like to draw your attention to the following:

- **Please do not transfer external calls to an external mailbox, to information systems or to external parties before they have answered**
- **Try to avoid diverting calls to third parties before they have answered**
- **Cancel your calls by pressing the "Clear"-key**

If the external parties are not persons (mailbox, automated information or attendant systems, etc.), connections on external lines can last a long time, which can be costly. Moreover, such calls may occupy two of your system's external lines. You can restrict connections between the external lines by re-programming your system.

Please ask your system administrator or contact our service center for more information.

	Page		Page
Abbreviated numbers.....	31	External calls.....	8
Absent information.....	19	Extra handset.....	50
Account number.....	41	Fixed diversion.....	15
Adjust telephone.....	63	Follow me.....	18
Alarm interface unit.....	52	Function codes and required data.....	55
Answer a second call.....	7	Glossary.....	60
Answer calls.....	7	Group call pick up.....	38
Answer paging calls.....	34	Group facilities.....	34
Audible adjustments.....	57	Group hunting.....	37
Automated attendant.....	41	Group paging.....	34
Automatic call-back.....	9	Handset and loudspeaker volume.....	57
Background music.....	42	Headset.....	51
Block extension.....	47	Hold.....	13
Busy extension.....	9	Incoming calls.....	7
Bypass blocked extension.....	48	Individual abbreviated numbers.....	32
Bypass call forwarding.....	18	Individual diversion.....	16
Call forwarding.....	15	Individual hold.....	13
Call-back.....	9	Individual mailbox system.....	27
Camp-on.....	9	Information.....	19
Change cables.....	62	Inquiry.....	11
Check and store received messages.....	24	Install cables.....	62
Cleaning the telephone.....	63	Install stand.....	62
Common abbreviated numbers.....	31	Intercom line.....	42
Common bell.....	39	Internal calls.....	8
Common hold.....	14	Internal messages.....	23
Common mailbox system.....	28	Intrusion.....	9
Conference.....	13	IP calls.....	46
Conference unit.....	52	Key system.....	35
Conversation recording.....	26	Lamp indications.....	56
Description.....	5	Last external number redial.....	8
Dial-by-name.....	31	Least Cost Routing.....	49
Dictaphone.....	25	Loudspeaker paging.....	34
Direct Inward System Access (DISA).....	44	Mailbox system.....	27
Diversion.....	15	Make calls.....	8
Doorlock.....	45	Monitoring.....	10
Doorphone.....	45	Music.....	42
During calls.....	10	Mute.....	10
Enter information.....	19	Networking.....	46
Erase information.....	22	Night switching.....	42

	Page		Page
Opening of the doorlock .....	45	Save information.....	22
Option unit .....	50	Second telephone.....	43
Optional equipment .....	50	Security.....	47
Other useful facilities.....	40	Select password .....	47
Outgoing calls .....	8	Send message.....	23
Paging group.....	34	Supervision/telephone attendance.....	36
Password .....	47	Tandem configuration .....	43
Personal greeting.....	30	Tape recorder .....	50
Placing the telephone.....	63	Tones and signals.....	59
Pre-defined texts .....	20	Transfer.....	12
Programming.....	53	Two telephones .....	43
Redial number.....	8	Un-block extension.....	47
Refer back.....	11	Useful hints .....	64
Reminder.....	40	Visible signals .....	56
Ringing character.....	58	Voice information.....	21
Ringing signal.....	57	Voice messages.....	23
Ringing type.....	57	Volume .....	57
Ringing volume .....	58	When you receive busy tone .....	9
Save external number.....	8		

## ANSWER CALLS

Answer:



Answer on another extension:



(Call ringing extension) **6**

## MAKE CALLS

Normal calls:



(Extension no.)

or



(External no.)

Common abbreviated number:



(Abbreviated no.)

Dial by name:



Ericsson

Individual abbreviated number:



(Abbreviated no. 0-9)

Last external number redial:



## YOU GET BUSY TONE OR NO ANSWER

Automatic call-back:



(Lift handset when called back)

Camp on:



(Keep handset off book)

Intrusion:



## DURING CALLS

Monitoring:



Individual hold:



(Flashing key to retake)

## INQUIRY

Ongoing conversation:

**Inquiry**



(Call 3rd party)

Back to first party:



**Line**

## REFER BACK

Press flashing key to connect:

**Line** or **Inquiry**

## CONFERENCE

Ongoing conversation:

**Inquiry**



(Call 3rd party)

**Message/Conference**

## TRANSFER

Transfer a call:

**Inquiry**



(Call 3rd party)



(Before or after answer)

## MESSAGES

"Call me":

**Message/Conference** **#**

Voice:

**Message/Conference**

**9** Speak

Play-back:



Re-record:



Speak

Send:



Receive messages:

**Message/Conference**

## CALL FORWARDING

Fixed diversion:

**\*** **2** **1** **#** **C**

Individual internal diversion:

**\*** **2** **1** **\*** **C**

(New no.) **#** **C**

Cancel internal diversion:

**#** **2** **1** **#** **C**

Follow me, re-direct from answering extension:

**\*** **2** **1** **\***

(Own no.) **\***

(New no.) **#** **C**

Cancel from ans. extension:

**#** **2** **1** **\*** **C**

(Own no.) **#** **C**

Bypass call forwarding:

**\*** **6** **0** **\***

(Extension no.) **#**

## INFORMATION

Enter information (pre-text):

**\*** **2** **3** **\***

(Select "info code" from list below)

(Enter "completing info")

**#** **C**

Erase information:

**#** **2** **3** **#**


	info code	completing info
Time of return	1.	hour (00-23) minute (00-59)
Date of return	2.	month (01-12) day (01-31)
Lunch	3.	back at, hour minute
Meeting	4.	back at, hour minute
Vacation	5.	back, month day
Illness	6.	back, month day




# QUICK REFERENCE CARD

These cards are used for DISA and to check messages.


## DISA and Message check:




## DISA and Message check:



## DISA and Message check:




## DISA and Message check:



# QUICK REFERENCE CARD


## Special account numbers for business calls:



*business* phone  
...it's your business

This is a part of EN/LZTBS 102 193 R4A


## Special account numbers for business calls:



*business* phone  
...it's your business

This is a part of EN/LZTBS 102 193 R4A


## Special account numbers for business calls:



*business* phone  
...it's your business

This is a part of EN/LZTBS 102 193 R4A

## Special account numbers for business calls:



*business* phone  
...it's your business

This is a part of EN/LZTBS 102 193 R4A

*Communication is our business*

Ericsson is the leading communications supplier, combining innovation in mobility and Internet in creating the new era of mobile Internet. Ericsson provides total solutions covering everything from systems and applications to mobile phones and other communications tools. With more than 100,000 employees in 140 countries, Ericsson simplifies communications for customers all over the world.

Read more at <http://www.ericsson.com/pressroom>

**Austria**

Ericsson Austria AG  
Pottendorfer Strasse 25-27  
A-1121 Vienna, Austria  
Telephone: +43-1-81 100-5450  
Telefax: +43-1-81 100-5437  
<http://www.ericsson.at>

**Australia**

Ericsson Australia Pty Ltd.  
Ericsson Business Systems  
126-142 Trenerry Crescent  
Abbotsford Vic 3067, Australia  
Telephone, sales: +61-13-1374  
Service: +61-1800-033-216  
Telefax: +61-9284-5776  
<http://www.ericsson.com.au/AU/>

**United Kingdom**

Enterprise Distribution  
Enterprise Networks and Datacomms  
Telecommunications Centre  
Ericsson Way, Burgess Hill  
West Sussex RH15 9UB  
Telephone: +44-(0)1444-234567  
Telefax: +44-(0)1444-874299  
<http://www.ericsson.co.uk>